BOSS ALUMINIUM TRAY & CANOPY CARE GUIDE

....

Boss Aluminium Pty Ltd Ph. (03) 9729 3092 sales@bossaluminium.com.au 8/208 Canterbury Road, Bayswater North VIC, Australia



Congratulations on your purchase of your new Boss Aluminium Tray/Canopy! All of our products are designed and manufactured right here, onsite in Bayswater, Victoria with the highest quality and attention to detail. To make sure your product lasts as long as possible, please find some information on how to clean and maintain your tray/canopy.

POWDER COAT CARING FOR YOUR POWDER COAT

How to wash and look after your powder coat

- Carefully remove any loose surface dirt with a wet sponge by gently rubbing.
- Clean by gently rubbing the surface with a soft brush (non-abrasive) and a dilute solution of a mild detergent and warm water to remove dust, salt, and any other grime.
- Avoid harsh chemical cleaners.
- Rinse surfaces with clean, fresh water after cleaning to remove any residue.

DO	DON'T
Protect all powder-coated joinery	Use aggressive solvents
Use high quality car wash only	Rub powder coated surfaces excessively
Regularly inspect powder coat	Allow sunscreen to come into contact with powder coated surfaces
Use non-abrasive cleaning tools	Neglect recommended care & maintenance schedules
Clean in mild conditions- surface temp be- low 25 degrees celsius	Use paint/metal polishing creams. (They are abrasive)



GENERAL CARE MAINTAINING YOUR TRAY & CANOPY

Top Maintenance Tips:

- Keep Canopy, Under Body Box & Under Tray Drawer gutters clear and clean to allow for drainage.
- Avoid exposing rubber seals to grease or oil to prevent swelling/cracking. This ensures the dust and waterproofing of the seals.
- Ensure tips of 3-point locking rods on all doors are always lightly greased for a smooth and easy locking action.
- Before driving vehicle, check all door handles are in the locked position and are not in open position whilst driving to prevent damage to doors.



Under Body Box Door Gutters



3-Point Locking Rod Ends



Canopy Rubber Seals

Canopy Removal

- 1. Park vehicle on flat ground where you wish to remove the canopy.
- 2. Unbolt the canopy from the internal canopy channels.
- 3. Remove wind-off point caps and insert wind-off legs in each corner.
- 4. Slowly wind off canopy, one corner at a time until there is sufficient clearance from tray deck.
- 5. Unplug any plugs from the front of the canopy (if applicable)
- 6. Check to see if there are any obstructions preventing vehicle from driving away.
- 7. Drive vehicle away. To ensure canopy sturdiness, lower legs for stability.
- 8. Done!

Maintaining Components

- Ensure wind-off legs are only operated manually, do not use an impact wrench.
- Inspect wind-off legs regularly before use for any defects or signs of wear.
- Keep runners of drawers/pantry/UTD clean for longevity.

Battery & 12v System

- Always follow battery manufacturer's instructions regarding charging/dis-charging battery.
- All 12v systems should be used in accordance to manufacturers specifications.

*Repeat steps in reverse to re-mount.

WATER TANK CARE & CLEANING

WARNING - DO NOT USE FULL MAINS PRESSURE TO FILL WATER TANK

Using full mains pressure to fill the water tank can cause cracking and major damage to the water tank due to the breather not able to release the air pressure so quickly. Please fill the tank slowly to ensure this does not happen.



Water Tank Filling Point



Water Tank Tap

Cleaning the Water Tank

- When not in use, ensure the under-tray water tank is always half full to create movement and help cleaning within the tank and prevent the tank starting to smell.
- Empty tank before refilling it with clean, fresh water.
- We recommend using Baby Bottle Steriliser or the Camec CleanOxide tablets. The instructions supplied with these options should be followed.
- Cleaning tablets are best used the evening before the water is needed to use.
- Add 1 Camec CleanOxide tablet to your water tank when filling. Leave to stand overnight, then water is ready to use.
- Please visit the respective cleaning tablet website for further information.



Boss Aluminium Pty Ltd Ph. (03) 9729 3092 sales@bossaluminium.com.au 8/208 Canterbury Road, Bayswater North VIC, Australia

1

ID

